



Chemicals



Electricity



Hot Liquids/Steam



Hot Surfaces



Moving Parts



Bucket, clean and sanitized towels



Bucket, soiled towels



Delimiting Tool



Bristle Brush



Kay® Peroxide Multi-Surface Cleaner Solution



Kay® SolidSense All Purpose Super Concentrate (APSC) Solution & Sanitizer Solution



Kay® Filter Pouch Cleaner

Tip Before starting, fill dispensers with enough iced tea to continue serving guests.



CAUTION: Surfaces/liquids may be hot.

Procedure

1. Place 3 pouches of **Filter Pouch Cleaner** in 3-position sink filled with clean, hot water (110-120°F).
2. Remove **Brew Basket** and **Dilution Sprayhead**.

NOTE: Remove **Dilution Sprayhead** by turning counterclockwise and pulling down to unlock.



Hot Surfaces
The sprayhead area is hot.



Hot Liquids/Steam
Hot water may have collected on the sprayhead during brewing.

3. Place **Brew Basket** and **Dilution Sprayhead** in sink containing cleaning solution.
4. Allow both to soak in solution for 15 minutes.
5. After 15-minutes, use the solution from sink and the supplied cleaning brush to scrub the **Brew Basket** and **Dilution Sprayhead**.
6. Rinse both in warm water.



continued >

Deep clean brew basket and dilution sprayhead (continued)

7. Sanitize both.



Chemicals

Filter Pouch Cleaner, Sanitizer Solution

8. Set out **Brew Basket** and **Dilution Sprayhead** to dry.

NOTE: Confirm both **Outer** and **Inner O-Rings** are still on the **Dilution Sprayhead** before installing in **Dilution Nozzle**.

9. Replace **Dilution Sprayhead**.

NOTE: Replace **Dilution Sprayhead** by pushing up and turning clockwise to lock.

10. Replace **Brew Basket**.

